


SOFTWARE UPDATE INSTRUCTION-EX-59 Elliptical

1. Complete the console setup. Follow Assembly Instruction until step 8 in the manual but do not need to insert bolts or handles.

Note: In order to save time, we can do ONE setup and update other consoles on it.



2. Download the software from the link below and save it in an empty USB drive.

<https://www.horizonfitness.com/support/software-updates>

3. Power ON the unit and “V1.xxx” should show shortly on the console.



4. Power OFF the unit and insert the USB drive.

5. Power ON the unit again with the USB drive inserted. The display should show as below.



6. Press ENTER button for installing the new software on the console. The display would go black for few seconds.



7. "S3.01" should show when it is complete.

8. Take off the USB and use it for other consoles.